



# L-Bracket-Kit



mk-messtechnik GmbH | FLM-Produkte | Zeppelinstr. 1 | 73274 Notzingen | Germany  
Tel. + 49 70 21 / 9 28 07-53 | E-Mail: [flm@mk-messtechnik.de](mailto:flm@mk-messtechnik.de) | [www.flm-gmbh.de](http://www.flm-gmbh.de)

## Assembling-Instructions for L-Bracket Kit



The kit consists of 3 essential components: The two photo plates QRP-130 and QRP-160 as well as the angle piece with 4 holes. There are M5 threads in the holes. The matching screws (5 pcs.) and the required Allen key are also included in the kit.



First screw the angle piece to the QRP-160 using 2 screws as shown in the right sided picture. Make sure that 3 holes are visible on the right side. Tighten the screws only slightly at first and only tighten them finally after mounting the second plate.



Now screw the QRP-130 with the remaining 3 screws against the QRP-160. Then tighten all screws moderately. This makes the L-angle operational.



FLM wishes you lots of fun with your new equipment.

mk-messtechnik GmbH | FLM-Produkte | Zeppelinstr. 1 | 73274 Notzingen | Germany  
Tel. + 49 70 21 / 9 28 07-53 | E-Mail: [flm@mk-messtechnik.de](mailto:flm@mk-messtechnik.de) | [www.flm-gmbh.de](http://www.flm-gmbh.de)